

### TEST PROCEDURE:

1. Remove test strip from foil packet and hold colored end of strip under running water for **10 seconds** (Method B).
2. Remove strip.
3. Wait 30 seconds.
4. Fold the white plastic handle of the test strip under the aperture so that it produces a white viewing background (See figure below).
5. Match to the color chart below and circle the option that matches best. Complete color matching within 15 seconds. Write corresponding number result under Total Cl<sub>2</sub> section in Chain of Custody.

#### Method B (10 second dip)



### PROCEDIMIENTO DE PRUEBA:

1. Retire la tira reactiva del paquete de aluminio y mantenga el extremo coloreado de la tira bajo el chorro de agua durante **10 segundos** (Metodo B).
2. Retire la tira.
3. Espere 30 segundos.
4. Doble el mango de plástico blanco de la tira reactiva debajo de la abertura para que produzca un fondo de visualización blanco (consulte la figura de abajo).
5. Compare con la tabla de colores a continuación y circule la opción que mejor combine. Haga esta comparación dentro de 15 segundos. Escriba el resultado numérico correspondiente bajo la sección de Total Cl<sub>2</sub> en el documento Chain of Custody.

